

A Member of the
ASEPT Group



Bereila *Sauce Bar*



The benefits of the Bereila Sauce Bar

- ▶ *Electronic Temperature Control*
- ▶ *Sauces stay fresh and tasty for longer*
- ▶ *Adjustable and constant portion size (NEOdis)*
- ▶ *Easy, smooth operation*
- ▶ *Dispensers can be dismantled easily and completely*
- ▶ *Dispensers and containers can be properly cleaned quickly*
- ▶ *Robust and solidly-built high quality product*
- ▶ *36-month guarantee on NEOdis dispensers*



The quality of the original

The original Bereila Sauce Bar has for many years been a widely used system for portioning hot and cold sauces such as mustard, ketchup, curry sauce and of course peanut sauce.

The Sauce Bar is highly suitable for snack bar and fast food operations, but certainly also for restaurants, company canteens and numerous other locations where food is prepared.

Tried and tested quality

The Bereila Sauce Bar is made of stainless steel and high-quality materials and components. The system is robust and solidly built. That adds up to a long life cycle, outstanding ease of use and maximum efficiency.

The heated Bereila Sauce Bar

The heated "au-bain-marie" version of the Bereila Sauce Bar is available with one, two or three sauce containers. The heated Sauce Bar has one or more NEOdis lever dispensers. Bereila supplies special dispensers for sauces with small pieces of vegetables, such as gypsy sauce, and there is also one specifically for chocolate sauce.

Hot sauces ideally maintain their temperate without caking. The sauce stays fresh and tasty. The heated Bereila Sauce Bar has a heating system consisting of a stainless steel heating element and an electronic thermostat that can be set to a maximum of 90 degrees Celsius. The Sauce Bar also features a safeguard against boiling dry that prevents the heating element from burning if there is no or not enough water in the system.

The unheated Bereila Sauce Bar

The unheated Sauce Bar is also available in a model with no fewer than four sauce containers. The unheated Sauce Bar is supplied with the high quality NEOdis

dispensers, but is also available with the Bereila BCMK push-button dispensers.

Maximum ease of use and hygiene

Both the heated and the unheated Sauce Bars are equipped with one or more plastic sauce containers that have an effective content of 2.5 litres. These containers are made of high-quality plastic and are especially suitable for contact with foods. They have large, rounded corners. A unique aspect is that the sauce doesn't stick to the container, which makes it easy to quickly clean it properly.

Bereila, dispenser specialist since 1971

Apparatenfabriek Bereila B.V. is the leading specialist in sauce dispensing systems for the catering and food service sectors.

Bereila's sauce dispensers for portioning hot and cold sauces are of the highest quality, feature a long life cycle and are exceptionally user-friendly.

The systems are easy to operate, clean and maintain.

As well as its standard product range, Bereila specialises in the development and manufacture of customer-specific dispensing solutions, private label and OEM products.

Apparatenfabriek Bereila B.V. is a member of the ASEPT Group.

Bereila heated Sauce Bars with stainless steel NEOdis dispensers

Article number	Description	Connection values	W x D x H (in mm)
11002000	Heated 2-piece with 1 stainless steel NEOdis dispenser and 1 lid	230V 1200W	245 x 200 x 330
11002020	Heated 2-piece with stainless steel NEOdis dispensers	230V 1200W	245 x 200 x 330
11003000	Heated 3-piece with 1 stainless steel NEOdis dispenser and 2 lids	230V 1200W	370 x 200 x 330
11003020	Heated 3-piece with 2 stainless steel NEOdis dispensers and 1 lid	230V 1200W	370 x 200 x 330
11003030	Heated 3-piece with 3 stainless steel NEOdis dispensers	230V 1200W	370 x 200 x 330

Bereila unheated Sauce Bars with stainless steel NEOdis dispensers

Article number	Description	W x D x H (in mm)
12001000	Unheated 1-piece with stainless steel NEOdis dispenser	140 x 200 x 235
12002000	Unheated 2-piece with 2 stainless steel NEOdis dispensers	245 x 200 x 235
12003000	Unheated 3-piece with 3 stainless steel NEOdis dispensers	370 x 200 x 235
12004000	Unheated 4-piece with 4 stainless steel NEOdis dispensers	490 x 200 x 235

Bereila unheated Sauce Bars with BCMK push button dispensers

Article number	Description	W x D x H (in mm)
14001000	Unheated 1-piece with BCMK push button dispenser	140 x 200 x 235
14002000	Unheated 2-piece with 2 BCMK push button dispensers	245 x 200 x 235
14003000	Unheated 3-piece with 3 BCMK push button dispensers	370 x 200 x 235
14004000	Unheated 4-piece with 4 BCMK push button dispensers	490 x 200 x 235

Accessories

Article number	Description
19100002	Plastic container, 3 litres
19100004	Stainless steel lid with button
19100006	Stainless steel NEOdis dispenser
19100008	Stainless steel NEOdis dispenser, special chocolate model
19100010	Stainless steel NEOdis dispenser, special shashlik sauce model
19100012	BCMK Sauce Bar dispenser
90100002	Spare part set NEOdis dispenser: 2 O-rings and 1 spring
90104002	Spare part set BCMK dispenser: 1 O-ring and 1 spring

NEOdis

A Member of the
ASEPT Group



Industrieweg 7a,
NL-9781 AC Bedum
The Netherlands

T +31 50 3012297
E info@bereila.nl
W www.bereila.nl